

Smartline®

WIRELESS PRO

True Wireless Earbuds with Hybrid ANC



Please refer to this user manual before using the product

16775

CONTROLS / KONTROLLER

EN

- Single tap right
- Single tap left
- Double tap either side
- Triple tap right
- Triple tap left
- Tap 4 times either side
- Touch and hold either side
- Touch and hold right
- Touch and hold left
- Volume Up
- Volume Down
- Play/Pause/Answer/End Call
- Next Song
- Previous Song
- Voice Assistant
- Reject Call
- Mode Switching
- Spatial Audio

SE

- Klicka en gång höger
- Klicka en gång vänster
- Dubbklicka på valfri sida
- Klicka 3 gånger höger
- Klicka 3 gånger vänster
- Klicka 4 gånger på valfri sida
- Tryck och håll inne valfri sida
- Tryck och håll inne höger
- Tryck och håll inne vänster
- Höja volymen
- Sänka volymen
- Spela/Pausa/Svara/Avsluta Samtal
- Nästa Låt
- Föregående Låt
- Röstassistans
- Neka Samtal
- Växla Läge
- Rumsligt Ljud

EN

POWER ON & OFF

- The earbuds will automatically turn on, once opening the charging case.
- The earbuds will automatically turn off once placed inside the charging case with the lid closed.

PAIRING

- Open the charging case
- Long press the charging case button for 5 seconds.
- Select "Add Device" and select Wireless Pro from the list of devices.
- Your Wireless Pro are now paired with your device and ready to use.

RESET

- Long press the charging case button for 10 seconds
- The White LED on the earbuds and charging case will start blinking, to indicate earbuds have been reset.

SE

STARTA & STÄNGA AV

- Hörlurarna kommer automatiskt att starta igång när etuiet öppnas.
- Hörlurarna kommer automatiskt att stängas av efter att de blivit placerade i etuiet med locket stängt.

PARKOPPLING

- Öppna etuiet.
- Håll inne etuiets knapp i 5 sekunder.
- Välj "lägg till enhet" och välj Wireless Pro från listan av enheter.
- Dina Wireless Pro är nu kopplade med din enhet och är redo för användning


Återställ

- Håll inne etuiets knapp i 10 sekunder.
- Den vita LED ljuset på hörlurarna samt etuiet kommer nu att börja blinka, för att indikera att hörlurarna har startats om.

Contents



Charging case x 1



USB Type-C charging cable x 1



Ear-tips

Safety Information

Before using and operating the earphones, please read and follow the precautions below to ensure optimal performance and to avoid dangerous situations.

Hearing Loss

- Listening to sound at high volume may permanently damage your hearing. When using earphones to listen to music or calls, it is recommended to use the minimum volume necessary to avoid harming your hearing.
- Exposure to high-level volume while driving may distract your attention and cause accidents.

Operating environment

- Do not use the device in dusty, sharp, compact spaces, or near magnetic fields to avoid damaging the device's internal circuitry.
- When installing the device, keep it away from strong magnetic fields, or electrical appliances with strong magnetic fields, such as ovens and refrigerators.
- Do not use the device in thunderstorm conditions, as thunderstorms may cause equipment failure or pose an electric shock hazard.
- Use the device within a temperature range of -10°C to +55°C, and store the device and its accessories within a temperature range of 40°C to +70°C. Excessive temperatures may cause the device to malfunction. When the temperature is below 5°C, the battery's performance is limited.
- Do not place the device in direct sunlight, such as on a car's dashboard or windshield.
- Do not place the device near heat sources or exposed flames, such as electric heaters, ovens, water heaters, stoves, candles, or other places that may generate high temperatures.
- Do not place sharp metal objects, such as pins, near the device's earpiece or speaker, as these metal objects may stick and cause injury.

Child safety

- This device and its accessories may contain small parts. Keep the device and its accessories out of children's reach. Children may inadvertently damage the device and its accessories, or swallow small parts, leading to suffocation or other hazards.
- This device is not a toy; children should use it under adult supervision.

Battery safety

- Do not disassemble or modify the battery, or immerse it in water or other liquids, as this may cause leakage, overheating, fire, or explosion.
- Do not drop, crush, or puncture the battery, as this can cause internal short circuits and overheating.
- This device is equipped with a non-removable built-in battery.
- Do not replace the battery yourself, as doing so may damage the battery or the device.

Charger safety

- When charging the device, the power socket should be installed near the device and be easily accessible.
- Once charging is complete or if the device is not charging, disconnect the charger from the device and unplug it from the power outlet.

Precautions

- The earphones should be stored in a dry, well-ventilated environment, and should avoid contact with oil, water vapor, steam, moisture, and dust to prevent performance issues.
- Avoid using harsh organic solvents or products containing these substances to clean the earphones.
- The earphones should be used according to the instructions, and attention should be paid to the environment's effect on the product. Ensure the connection is stable and maintain a recommended distance of no more than 10 meters between the devices.
- If the earphones fail to connect or experience poor connection, please do not attempt to disassemble them or their accessories yourself, as this will void the warranty.
- When charging the earphones, use the standard car charger or the charger specified by us.
- To ensure proper use of the earphones, please ensure they are fully charged.



Smartline is a Swedish brand owned and manufactured by Proove Distribution AB.
www.smartlinesweden.com - info@smartlinesweden.com
Bjergerssens Väg 348, 432 40, Varberg, Sweden

EN

Säkerhetsinformation

Ennen kuin käytät kuulokkeita, lue ja noudat alla olevia käyttöohjeita ja varoituksia optimaalisen suorituskyvyn ja turvallisuuden varmistamiseksi.

Hörselskada

- Att lyssna på ljud på hög volym kan permanent skada din hörsel. När du använder hörlurar för att lyssna på musik eller svara rekommenderas det att du håller volymen så låg som möjligt, bara tillräcklig för att höra musiken eller samtalet, för att undvika att skada din hörsel.
- Exponering för hög volym under körning kan distrahera din uppmärksamhet och orsaka olyckor.

Användningsområden

- Undvik inte enheten i dammiga miljöer, nära varma föremål, i trånga utrymmen eller nära magnetiska fält för att undvika skador på enhetens interna kretsar.
- Vid installation, håll enheten borta från starka magnetiska fält eller elektriska apparater med starka magnetiska fält, såsom ugnar och kylskåp.
- Använd inte enheten under åskväder, då detta kan orsaka enhetens eller elchockrisk.
- Använd enheten inom ett temperaturområde på -10°C till +55°C och förvara enheten och dess tillbehör inom ett temperaturområde på -40°C till +70°C. För hög eller för låg omgivningstemperatur kan orsaka funktionsfel på enheten. När temperaturen är under 5°C begränsas batteriets prestanda.
- Placera inte enheten i direkt solljus, till exempel på bilens instrumentbräda eller försterbräda.
- Placera inte enheten nära värmeåskåp eller öppna eldskåp, såsom elektriska värmare, ugnar, värmepannor, spisar, ljus eller andra föremål som kan generera höga temperaturer.
- Placera inte varsa metallföremål, som nålar, nära enhetens hörlursdel eller högtalare, då dessa kan fastna och orsaka skador.

Barnsäkerhet

- Denna enhet och dess tillbehör kan innehålla små delar. Förvara enheten och dess tillbehör på en plats utom räckhåll för barn. Barn kan oavsiktligt svälja enheten och dess tillbehör eller svälja små delar, vilket kan orsaka skador eller andra faror.
- Denna enhet är inte en leksak; barn bör använda enheten under vuxens tillsyn.

Batterisäkerhet

- Montera eller modifiera inte batteriet, och släng det inte i vatten eller andra vätskor för att undvika läckage, överhettning, brand eller explosion.
- Appa inte, krossa inte och punktera inte batteriet, eftersom det kan orsaka interna kortslutningar och överhettning.
- Denna enhet är utrustad med ett icke-avtagbart inbyggt batteri.
- dyt inte ut batteriet själv, för att undvika skador på batteriet eller enheten.

Laddarsäkerhet

- När enheten laddas bör strömtätheten vara installerad nära enheten och vara lätt åtkomlig.
- När laddningen är klar, eller om enheten inte laddas, koppla bort laddaren från enheten och ta ut den från eluttaget.

Försiktighetsåtgärder

- Hörlurarna bör förvaras i en torr och ventilerad miljö och undvik kontakt med olja, vattenångor, ånga, fukt och damm för att förhindra att produktens prestanda försämras.
- Undvik att använda starka organiska lösningsmedel eller föremål som innehåller dessa ämnen för att rengöra hörlurarna.
- Hörlurarna bör användas enligt installationsöms och vara uppmärksamma på miljös påverkan på produkten. Se till att anslutningen är stabil och håll ett avstånd på högst 10 meter mellan enheterna.
- Om hörlurarna inte kan anduta eller om anslutningen är dålig, vänligen montera inte ner dem eller tillbehören på egen hand. Anslut dem till garantin.
- Vid laddning av hörlurarna, använd den standard-laddare eller laddare som specificerats av vårt företag.
- För att säkerställa normal användning av hörlurarna, vänligen se till att de är fullt laddade.